


FS-805 D4 Assembly Instructions


Bowers & Wilkins

1


a 2x



b 2x



f 2x



c 12x



d 8x



e 8x



g 12x



h 12x



i 8x




j 1x
3mm




k 1x
4mm



l 1x





m 1x




2


a




b



a




b




3


c








b



a







B&W Group Ltd
 Dale Road
 Worthing West Sussex
 BN11 2BH England

EU Importer:
 Bowers & Wilkins
 Beemdstraat 11
 5653 MA Eindhoven
 The Netherlands

Copyright © B&W Group Ltd. E&OE

